

07 decotric Wallpaper and Border Adhesive decotric Wandbelags- und Borduerenkleber

Ready to use, solvent-free emulsion-based adhesive for heavyweight wall coverings, textile wallpapers and borders.

Instructions for use:	For pasting textile wall coverings, woven fabric wallpapers, glass cloth, PVC foils with woven backings as well as for use as a wallpaper adhesive additive								
Technical specifications:	<table border="0"> <tr> <td>Components:</td> <td>Polyvinyl acetate ethylene emulsion</td> </tr> <tr> <td>pH-value:</td> <td>approx. 9</td> </tr> <tr> <td>Density:</td> <td>approx. 1,03 g/cm³</td> </tr> <tr> <td>Usage:</td> <td>200-300 g/m²</td> </tr> </table>	Components:	Polyvinyl acetate ethylene emulsion	pH-value:	approx. 9	Density:	approx. 1,03 g/cm ³	Usage:	200-300 g/m ²
Components:	Polyvinyl acetate ethylene emulsion								
pH-value:	approx. 9								
Density:	approx. 1,03 g/cm ³								
Usage:	200-300 g/m ²								
Surface preparation:	The surface must be dry, firm, dust and grease-free. Remove old, peeling wallpapers and flaking paints using <i>decotric Wallpaper Remover</i> . Make good cracks and holes using <i>decomur Super Bonding Filler</i> or <i>decofill Interior</i> . Pretreat highly absorbent, sanding or chalking surfaces using <i>decotric Penetrating Primer – Solvent Free</i> .								
Application:	<p><u>As a wall covering adhesive:</u> Evenly apply <i>decotric Wallpaper and Border Adhesive</i> to the surface over a width equal to the width of the wall covering using a roller or brush and place the wall covering, cut to size, in the moist adhesive bed. If the adhesive is to be applied directly to the wall covering, observe the prescribed softening time. Always observe the wall covering manufacturer's pasting guidelines!</p> <p><u>As a border adhesive:</u> Moisten the borders with water and then apply a thin, uniform coat of <i>decotric Wallpaper and Border Adhesive</i> to the border. Fold the pasted ends of the borders together, roll up and leave to soften. After the prescribed softening time place the border on the surface and uniformly press into place.</p> <p>Observe the border manufacturer's instructions for use!</p> <p><u>As an additive for wallpaper adhesive:</u> <i>decotric Wallpaper and Border Adhesive</i> can be used to increase the adhesive strength and moisture resistance of wallpaper adhesives. Thoroughly stir <i>decotric Wallpaper and Border Adhesive</i> into the already dissolved wallpaper adhesive. The optimum amount to be added is approx. 15-20 % e.g. a 750-g tin of <i>decotric Wallpaper and Border Adhesive</i> to 4 l stirred wallpaper adhesive.</p> <p>Immediately remove residual adhesive using a damp cloth. Do not use if the surface and/or room temperature are below + 5° Celsius! Clean tools in water after use.</p>								
Storage:	Store in a cool place! Keep containers tightly sealed! The adhesive is frost-resistant. If frozen, defrost in room temperature and stir before use.								
Article no.:	07								
Available sizes:	<table border="0"> <tr> <td>750 g PE can</td> </tr> <tr> <td>3 kg PE tub</td> </tr> <tr> <td>5 kg PE tub</td> </tr> <tr> <td>10 kg PE tub</td> </tr> </table>	750 g PE can	3 kg PE tub	5 kg PE tub	10 kg PE tub				
750 g PE can									
3 kg PE tub									
5 kg PE tub									
10 kg PE tub									