



Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips



Mechanical cleaning equipment

Auto scrubber, rotocleaner or single-brush machine



Mechanical cleaning disk

3M (or equivalent) colour disks



Manual washing equipment

Disposable microfiber mop or gauze



Steam cleaning equipment

Follow the manufacturer's recommendations



Manual scrubbing equipment

Scrubbing brush

		Equipment used	Cleaning products	Cleaning methods
FLOORS	First use			
	Manual cleaning	 	Alkaline detergent	• Damp sweeping • Manual cleaning with a scrubbing brush • Recovery of solid water with a flat mop • Rinsing with clean water
	OR			
	Mechanical cleaning	  or  if soiled		• Damp sweeping • Mechanical washing at 300-450 rpm (with water recovery)
	Daily cleaning			
	Manual cleaning	 	Neutral detergent Disinfectant detergent ⁽¹⁾	• Damp sweeping • Manual washing with flat mop • Rinsing
WALLS ⁽²⁾	OR			
	Mechanical cleaning			• Steam cleaning
	Deep cleaning			
	Manual cleaning	 	Alkaline detergent	• Damp sweeping • Manual cleaning with a scrubbing brush • Recovery of solid water with a flat mop • Rinsing with clean water
	OR			
	Mechanical cleaning	 		• Damp sweeping • Mechanical washing at 300-450 rpm (with water recovery)
	Cleaning of walls		Neutral detergent	• Wall washing • Rinsing

⁽¹⁾ In areas where disinfection is essential (e.g. operating theatres, hospital rooms, etc.), alternate between using neutral detergent and amine-free disinfectant detergent.

⁽²⁾ For further informations, please refer to page 2.

These cleaning instructions have to be adapted depending on traffic and location of the area.

In the case of **manual maintenance** and to offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (complete spreading and cleaning of the entire floor surface).

Here is a non-exhaustive list of products recommended by the main manufacturers:

KIEHL : Profloor*, RS Nett**
TANA / WERNER : Green care
SR15*, Floor Cleaner S*, Clean
Fresh*, Difotan*, Clean Extreme*,
Innomat**

ECOLAB : Brial Clean S*
ANIOS : Deterg'anios*
ROCHEX : Polystar*, Roctonic**
BUZIL : HC 43**
Dr. SCHUTZ : PU Reiniger**

DIVERSEY / SEALED AIR: Asset*
DREITURM : Multinetzer*,
Goldreif (vert)*, Linorein**,
D1 Neu**

*Neutral / **Alkaline

MAINTENANCE PROTOCOL FOR WALL COVERINGS

MURAL CALYPSO / MURAL ULTRA / MURAL CLUB



Damp maintenance equipment

Sponge without abrasive



Manual washing equipment

Disposable microfibre mop or gauze

	Equipment used	Cleaning products	Cleaning methods
First use	  without abrasive	Alkaline detergent	• Manual cleaning with an alkaline detergent + sponge without abrasive • Recovery of water with a microfibre disposable mop • Rinsing with clear water
Daily cleaning	 without abrasive	Neutral detergent or disinfectant detergent	• Manual cleaning with a sponge without abrasive + neutral detergent for the surfaces located in areas 1 or 2 and a disinfectant detergent for the surfaces located in areas 3 and 4 and eventually in area 2 or • Steam cleaning
Periodical cleaning	 without abrasive	Disinfectant detergent	• Manual cleaning with a disinfectant detergent (without amine) and a sponge without abrasive or • Steam cleaning (if manual daily maintenance)
Deep cleaning	 without abrasive	Alkaline detergent	• Manual cleaning with an alkaline detergent + a sponge without abrasive • Rinsing with clear water

These cleaning instructions have to be adapted depending on traffic and location of the area.

In the case of **manual maintenance** and to offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (complete spreading and cleaning of the entire floor surface).

Here is a non-exhaustive list of products recommended by the main manufacturers:

KIEHL : Profloor*, RS Nett**
TANA / WERNER : Green care
 SR15*, Floor Cleaner S*, Clean
 Fresh*, Difotan*, Clean Extreme*,
 Innomat**

ECOLAB : Brial Clean S*
ANIOS : Deterg'anios*
ROCHEX : Polystar*, Roctonic**
BUZIL : HC 43**
Dr. SCHUTZ : PU Reiniger**

DIVERSEY / SEALED AIR: Asset*
DREITURM : Multinetzer*,
 Goldreif (vert)*, Linorein**,
 D1 Neu**

*Neutral / **Alkaline

PRECAUTIONS FOR USE



- Never use abrasive disks or any procedure that risks damaging the surface treatment (abrasive products, solvents, etc.).
- Never use rubber caps (for chair legs or other furniture); instead, use PVC or Polyethylene caps.

STAIN REMOVAL DURING WORKS

Paint mark removal

- Do not use abrasive cleaning equipment (e.g. Scotch Brite, scouring pads, steel wool, etc.).
- Use the solvent for the paint if known. If the solvent is not known, start with solvents such as Essence C, White Spirit, etc. before trying stronger solvents such as Taraclean spray. If the stain proves hard to remove, do not persist.
- Wipe and rinse the floor thoroughly after applying the solvent.

On paint drips

A freeze spray will yield excellent results when paint has formed a drip on the material (freeze sprays can be bought from cleaning product manufacturers or in pharmacies).

On adhesive marks

- Fresh acrylic adhesive marks (< 1 month)
Apply a water-based solution with added cleaning product, leave to act and mechanically clean and rinse the floor.
- Dried acrylic adhesive marks (> 1 month)
Use Essence C or White Spirit. Wipe and rinse the floor thoroughly after applying the solvent.
- Solvent adhesive marks
Use strong solvents (such as Taraclean spray), but do not persist if the adhesive marks are difficult to remove (as may happen with solvent-resistant cross-linked adhesives).

TIPS AND ADVICE FOR STAIN REMOVAL

Rust

Apply an anti-rust product or oxalic acid. Rinse thoroughly.

Food grease/paint/ballpoint pen/felt-tip pen/heavy grease (tar)

Apply a solvent such as Essence C or White Spirit. Rub with undiluted product and rinse with plenty of water.

Rubber marks/Shoe marks

Apply an alkaline detergent (such as Dynatech Trophy) to shoe marks. Leave to act for 5 minutes. Rub.

Chewing-gum

Use a freeze spray to harden the chewing gum, and then remove it with a plastic spatula (freeze sprays can be bought from cleaning product manufacturers or in pharmacies).